

Offset fixing plate











The BAC1XFPO offset fixing plate, when used in conjunction with the concealed hinge, allows a door to be hung offset to a wall or timber / metal post or door jamb where required.





Adjustment wedge

BACWEG Adjustment Wedge


An aid to assist in positioning the door when hanging using CEAM concealed hinges







Adjustment keys



	Α	В	Used for Models
BACKEY1	8	2,5	929, 1129, 1080,
			1030, 1230S,1430
BACKEY2	10	3	1131S, 1431

BACKEY Adjustment Keys

Used to adjust the position of the door via the hinge's 3D adjustment axis points. Used to remove the hinge from its cup so the door can be removed and re-hung.